

SoundScope MR DIN and RUSSOUND



Any compatible Russound Multi-room controller (CAA66 shown)

SoundScope MR DIN controls the Russound and supplies Metadata to the Russound keypads.

Connect the following cables between the PC and the controller.

- Green cables are audio cables with 3.5mm plugs on PC end and RCA plugs on controller end:



Red cable is control cable.

If PC has a built-in serial port, plug one end of a serial cable into PC and other end into controller.
If PC does not have built-in serial port, plug a USB to serial adapter into a USB connector on the PC.
Plug one end of a serial cable into the adapter and the other end into the controller.

